


PRONTO 2 SET-UP INSTRUCTIONS



Connector Pin Close Up



1. Remove unit from bag
2. Remove three sectioned mast from bag or from center of unit. Place unit horizontal on floor
Do not rotate the feet at bottom outward
3. Assemble three sectioned bungee corded mast into one complete pole.
Find silver unpainted end of mast (this is the bottom.)
Insert bottom of mast into the hole at top center of the unit so mast is perpendicular to the floor and unit.
Note: there is a hole at the top of the unit and a second hole at the bottom base of the unit. It is important that the mast go through the top hole and seat into the bottom hole. This keeps the mast straight up and secure under tension.
4. With the mast inserted into the unit find the silver hook at the center of the banner header furthest from you.
The silver hook is not a handle! It is there to hook the banner header to the top of the mast.
With one hand holding the mast center your other hand over the silver hook gripping the graphic header. Slowly and carefully pull the banner header upward while leaning the mast/unit toward you. Some people find it helpful to guide their fingers along the mast to keep the graphic gliding evenly from the unit.
If you see the graphic begin to touch the side of the unit stop immediately, allow the graphic to slowly retract and begin again. Once the graphic hook is close enough to the mast, hook it into the mast without letting go of the header bar.
5. Repeat extending graphic closest to you.
6. Stand the graphic upright and while holding the base of the unit rotate the stabilizer feet outward so they are perpendicular to the length of the base.
7. Install the connector pins.
 - Remove the plastic tabs at the end of the graphic headers (save)
 - Slide the round silver pin into the header circular channel
 - Tighten thumb screw.
 - Move second banner stand close enough to insert the connector pin
 - With the connector pin inserted into both units slide the two stands as close together as possible. Tighten thumb screw. Note. There will be some space between units. The connector pins are meant to keep the banners at the same angle from the floor not to create a seamless back wall. Use the connector pins in the back graphics to minimize their view.